

Outlined below are basic instructions for installing 20oz. Wall Covering. Through several installation testing procedures and in conjunction with the material manufacture, **following** these guidelines will make your installation **easier**. Please note that **not** all wall surfaces are finished the same (**Texture, Coating and Sealants.**) It is **strongly** recommended to locate an area of the surface which is not visible or less visible to the public to do your own **testing**.

STEPS ONE, TWO AND THREE

Upon receiving your printed Wall Covering, unpack and **check** the overall height and length by placing each panel edge to edge. Most printed Wall Coverings come with **excess/bleed** built into the background to allow for adjustments needed during application. Having the measurements of the printed product, measure the area of the actual wall the Wall Covering will be applied to. **Compare** the two measurements. It is **essential** that the printed Wall Covering is slightly **larger** than the wall area. If not, check your order to assure the printed Wall Covering was printed at the **correct size**.

STEPS FOUR, FIVE, SIX AND SEVEN

We **strongly** recommend taking each panel starting at one end and placing and taping the panel on the wall surface. Line up the second panel with a tight **butt joint** to the first panel. Repeat this process until all panels are hung and then **visually review** the panels. Visualize or reference any **obstructions** which could interfere with the Wall Covering. Make necessary **adjustments** when you start the actual installation to **avoid** obstructions. Remove all panels and keep them in **order** of installation. It will reduce your installation time by not having to hunt for the proper panel. Wipe down the entire wall surface **removing** all dust. Remove any electrical plug covers or similar covers. Inspect the surface for any extremely sharp points of plaster as it will be noticeable through the Wall Covering. If the wall surface has any holes or torn paper or texture, it should be re-patched to lessen any visible reflection of that area. We **strongly** recommend discussing these areas with the end user before application. If it is determined to **repair** any surface area by re-plastering the surface, do **not** apply the Wall Covering for a **minimum of 24 hours** to allow the plaster to **cure**. Your wall area is now ready for installation. You need to **prep** the wall surface and **prime** the wall with a vinyl sealant. We recommend **Roman Pro 909 Primer** (this can be found at a Lowe's, Sherwin Williams or similar store.) Using a tight nap roller, cover the entire wall and smooth out the primer, do **not** leave thick density or **uneven** density. Allow to dry for a **minimum of three hours**. We **highly** recommend to tape off areas you do **not** want sealant to make contact with (ceiling frame, door jams, electrical sockets etc. as sealant **does not remove easily**.)